

Novo7 Advanced/Advanced-II User Guide And Market Script

By [Ivan Sarmiento](#) in [Ainol Novo7 Tablets](#) *[TipidPC Members](#)* · [Edit Doc](#) · [Delete](#)

Section #1: Firmware Upgrading Step by Step Procedure.

Section #2: Full Android Market Script.

=====
Novo7 Advanced Firmware Download Link:

GB_2.0_Feiyu: <http://www.mediafire.com/?5v947unyammcx6g>

GB_2.0.3_Feiyu: <http://www.mediafire.com/?5ddqjy2ahhk3b>

ICS_4.0.3 Official Firmware: <http://www.mediafire.com/?4rtyd2e196xdd>

=====
Novo7 Advanced-II Firmware Download Link:

No Available Firmware Release yet...

=====
Firmware Upgrade Tool and Drivers:

USB Driver: <http://www.mediafire.com/?1p4ln5yn2u7v5jb>

LivesuitPack_v1.07: <http://www.mediafire.com/?d1yqpja5mrlnznz>

Additional USB Driver: <http://www.mediafire.com/?mlmddg7373mkubn>

- If Device not found error appear while installing the FullMarket Script.
- Power-ON your Tablet > Go to System Settings > Developers Option.
- Enable USB Debugging & Stay Awake. Connect Tablet to PC.
- Open Device Manager and right-Click Android Device.
- Install driver manually and Choose Downloaded Driver location.

=====
Firmware Upgrading Step by Step Procedure

Video Tutorial: http://www.youtube.com/watch?v=9fqeSFuEs2A&feature=player_embedded

1. Check the current baseband/firmware installed. Go to Menu > Settings > About Device.
 - *Upgrade to above recommended firmwares if it's using different version.*
 - *Turn-On Tablet, go to Settings > Applications > Development. = For Gingerbread*
 - *Turn-On Tablet, go to System Settings > Developers Option. = For Ice Cream Sandwich*
 - *Turn-ON USB Debugging & Stay Awake.*
2. Connect the Tablet to PC and double-click DPInst to install the required USB Driver for your OS.
3. After installation, disconnect your Tablet to PC and Turn it OFF.
4. Extract the Livesuit Pack into a folder on your PC.
5. Place the Firmware .img file inside the Livesuit Pack folder and double-click Livesuit.exe:
 - *1st pop-up window click YES.*
 - *2nd pop-up window click FORMAT.*
 - *3rd pop-up window click NEXT.*
 - *4th pop-up window click YES.*
 - *5th pop-up window locate your selected FW image file and click OPEN.*
 - *6th pop-up window click FINISH.*
6. For Ainol Novo7 Advanced, press and hold the +Volume Button and connect the Tablet to PC.
7. For Ainol Novo7 Advanced-II, press and hold the -Volume Button and connect the Tablet to PC.
8. As soon as you connect the USB Cable to PC, rapidly press the Power button 6 times without releasing the Volume Button.
 - *7th pop-up window click: (YES = Complete Format) (NO = Re-Flash to same Firmware)*
 - *8th pop-up window click: (YES = Complete Format)*
9. You can now release the Volume Button and wait for the upgrading to get finished.
 - *9th pop-up window click FINISH or OK.*

=====
IF Firmware Upgrading Fails, just press Power button for 30seconds and do the Firmware Upgrading again.

=====

Gingerbread 2.3 After Finishing Firmware Upgrading:

1. Disconnect the tablet to PC and Power-ON your Tablet.
2. Go to Settings scroll down upto bottom and locate the [A] icon to change the Language.
3. Touch the very 1st option and choose English (US).
4. Go to Settings > Wireless and Networks > Wi-Fi Settings and Press Menu.
5. Click Advanced > Wi-Fi Sleep Policy and set it to NEVER.
6. Go to Settings > Applications > Development and turn-ON Stay Awake.
7. Go to Settings > Display > Screen Timeout and set it to 2mins above.
8. Go To Settings > Sound and disable Haptic Feedback (Vibrate).
9. Reboot your Tablet.

Ice Cream Sandwich 4.0 After Finishing Firmware Upgrading:

1. Disconnect the tablet to PC and Power-ON your Tablet.
 2. Go to System Settings scroll down upto bottom and locate the [A] icon to change the Language.
 3. Touch the very 1st option and choose English (US).
 4. Go to System Settings > Developers Option > Turn-ON USB Debugging & Stay Awake.
 5. Go to System Settings > Display > Sleep and set it to 2mins above.
 6. Go To Settings > Sound and set Vibrate to Never and Disable Vibrate on Touch.
 7. Reboot your Tablet.
- =====

Full Market Script Installation

Instructions:

Note: Script works best when tablet's firmware is fresh re-flash or newly flash.

- *Extract the .7z folder to PC and connect your Tablet powered-ON.*
- *Do not turn-ON USB Storage Mode.*
- *Double click the fullmarket.bat and follow the instructions.*

Novo7 Advanced GB FullMarket Script: <http://www.mediafire.com/?6o2c1s4jwsec160>

- For Stock/Official/Feiyu_Mod Gingerbread 2.3.4 Firmwares ONLY.
- Samsung Galaxy S-II fingerprints on build.prop for better Games Compatibility.
- Android 3.4.4 FullMarket, Google Apps installation and Root Function.
- Added Sony Bravia Engine and UI build.prop tweaks.
- New Novo7 Advanced bootanimation

Novo7 Advanced ICS FullMarket Script: <http://www.mediafire.com/?97f6a1ocuawwgxt>

- For Stock ICS 4.0.1 and Official ICS 4.0.3 Firmwares ONLY.
- Samsung Galaxy S-II fingerprints on build.prop for better Games Compatibility.
- Android 3.4.4 FullMarket, Google Apps, and Bravia Engine Installation.
- Added Apex Launcher - Fast ICS Style Launcher.
- New Novo7 Advanced bootanimation
- NO ROOT FUNCTION. Please Follow steps below to Root your Device:

=====

Novo7 Advanced-II ICS 4.0.1 FullMarket Script: <http://www.mediafire.com/?aep46bdzwal1k24>

- For Stock ICS 4.0.1 and Official ICS 4.0.3 Firmwares ONLY.
- Samsung Galaxy S-II fingerprints on build.prop for better Games Compatibility.
- Android 3.4.4 FullMarket, Google Apps, and Bravia Engine Installation.
- Added Apex Launcher - Fast ICS Style Launcher.
- NO ROOT FUNCTION. Please Follow steps below to Root your Device:

How Root your Device: *Credits to Almaz of Slatedroid.com*

1. Download and install Superuser from Android Market and open the program.
2. Go to Preferences and click on (Su binary vnull tap to check for updates)
3. Click update and Reboot the Tablet.
4. Download and install BusyBox Installer JRummy16 from Android Market. Open it.
5. Click Allow and install first to /System/Xbin directory.
6. Then install to /System/Bin directory. Reboot the Tablet.
7. Connect USB cable to your Tablet and double-click Root.bat