

# **GEM-701L**

## **SD-Card Upgrade User Guide**



Huawei Technologies Co., Ltd.

All rights reserved  
(DVP05T05 V1.2/ IPD-CMM V3.0)



## Contents

1	Directory list of SD-card upgrade package .....	3
2	SD-card Upgrade Process .....	3
2. 1	Notes: .....	3
2. 2	Process .....	3

## 1 Directory list of SD-card upgrade package

Please check the intactness of SD-card upgrade package.

--dload(directory)

-- UPDATE.APP (file)

Please check the intactness of inner SD-card upgrade package.

--dload(directory)

-- UPDATE.APP (file)


## 2 SD-card Upgrade Process

### 2.1 Notes:

- 1) Before SD-card upgrade, please backup your data.
- 2) Make sure your tablet has more than 20% power.
- 3) Make sure the SD-card has enough space (more than 4G) for copying upgrade file, and the format is FAT32 or NTFS.
- 4) Before finish upgrading, do not remove SD-card.
- 5) Do not power off when upgrading.

### 2.2 Process

- 1) Please copy dload directory(including UPDATE.APP and update\_vendor.app) to the root directory of SD-card or inner sdcard.
- 2) Click Settings and select Update




### 3) Select Menu




### 4) Select Local update




5) If the package is copied to inner sdcard, it shows as follows:



If the package is copied to external sdcard, it shows as follows:




- 6) Select “Full Package: UPDATE.APP” .



- 7) Select Install to start sdcard upgrade and reboot to recovery to do upgrade. The screen will display as follow during normal upgrade process:



8) If the upgrade succeeds, the phone will reboot. If update failed, the screen show as follows:



NOTICE: If upgrade failed, please check whether the upgrade file is intactness or not, or UPDATE.APP and update\_vendor.app is correctly put in SD-card or not.