

```
1: You need to download the flashable ZIP of SuperSU from https://magisk.me/supersu/
2: Unpack the ZIP file and find the file "su" in the folder arm64.
3: Copy the file "su" to the folder where ADB is installed.
4:
5:
6: adb connect [IP-Address of the unit]
7: adb root
8: adb connect [IP-Address of the unit]
9: adb remount
10: [adb disable-verity] <-- only on some devices needed if there is an error message
11: adb shell setenforce 0
12: adb push su /system/xbin/su
13: adb push su /system/bin/su
14: adb shell chmod 06755 /system/bin/su
15: adb shell chmod 06755 /system/xbin/su
16: adb shell /system/bin/su --install
17: adb shell /system/bin/su --daemon&
18: adb push rooting.rc /system/etc/init/rooting.rc
19:
20:
21:
22: After successful rooting, you need to install SuperSU from the market.
23: NEVER!!! press the Update button in SuperSU, because otherwise you will run into
    bootloop and
24: you need to flash the complete firmware again.
```