
5. MAIN Electrical Parts List

[SM-G975F]

Parts Code	Design LOC	Description
0401-001110	ZD8009	DIODE-SWITCHING
0404-001250	D8000,D9000	DIODE-SCHOTTKY
0406-001561	ZD9012	DIODE-TVS
0406-001709	ZD9009	DIODE-TVS
0406-001729	ZD8007,ZD8008	DIODE-TVS
0406-001781	ZD9007,ZD9011	DIODE-TVS
0406-001787	V9000,V9001,ZD11008	DIODE-TVS
0406-001787	ZD11019,ZD9000	DIODE-TVS
0406-001787	ZD9001	DIODE-TVS
0406-001804	ZD11006,ZD11007	DIODE-TVS
0406-001804	ZD11009,ZD11010	DIODE-TVS
0406-001804	ZD11017,ZD11018	DIODE-TVS
0406-001804	ZD11020,ZD11021	DIODE-TVS
0406-001805	ZD8003	DIODE-TVS
0406-001809	ZD11011,ZD11012	DIODE-TVS
0406-001826	ZD11002,ZD11022	DIODE-TVS
0601-003707	LED10000	LED
0801-003639	U8001	IC
0903-002233	U10003	IC
1001-001755	U9001	IC
1001-001975	U1003	IC
1001-002045	U8025	IC
1001-002075	F2001,U1002,U1004	IC
1009-001076	U11001,U5009	IC
1107-002573	UME4000	IC
1201-003735	U5007	IC
1201-004114	PAM1001	IC
1201-004157	PAM1000	IC
1201-004178	U9003,ZD9003	IC
1201-004210	U1005	IC
1202-001120	U12001	IC
1203-008472	U10002	IC
1203-008729	U4000	IC
1203-008802	U8008	IC
1203-008811	U5008	IC
1203-008867	U12002,U5006,U8035	IC
1203-009032	U12000	IC

5. MAIN Electrical Parts List

1203-009035	U10001	IC
1203-009080	U9002	IC
1203-009156	U8031	IC
1203-009168	U8003	IC
1203-009187	U8015	IC
1203-009191	U12003	IC
1204-003761	L1071	IC
1204-003773	U1001	IC
1205-005217	U10004	IC
1205-005729	U9000	IC
1205-005871	U5014	IC
1205-005880	U5002	IC
1205-006032	U3000	IC
1205-006044	UCP5000	IC
1209-002513	U5013	IC
1209-002558	U5011	IC
1209-002567	U5012	IC
1209-002578	U5010	IC
1209-002607	U11000	IC
1209-002608	U5004	IC
1209-002619	U5005	IC
1404-001724	TH11000,TH5000	THERMISTOR
1404-001724	TH6000,TH8000,TH8001	THERMISTOR
1404-001724	TH8002,V4000	THERMISTOR
1405-001395	V11003,V11010,V11011	VARISTOR
1405-001395	V11012,V11013,V11014	VARISTOR
1405-001395	V11018,V11019,V11020	VARISTOR
1405-001395	V11021,V2001,V2004	VARISTOR
1405-001403	V11024,V2003	VARISTOR
1405-001404	V11000,V11001,V11009	VARISTOR
1405-001404	V11015,V11026,V11027	VARISTOR
1405-001404	V11029,V2010,V2011	VARISTOR
1405-001404	V5012	VARISTOR
1405-001412	V1002	VARISTOR
1405-001415	V1003,V11023,V11025	VARISTOR
1405-001415	V11030,V11031,V2002	VARISTOR
1405-001415	V2008,V2009,V5005	VARISTOR
1405-001415	V5006	VARISTOR
1405-001420	R1003,V11002,V11004	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1405-001420	V11005,V11008,V11022	VARISTOR
1405-001420	V11028,V2000,V5002	VARISTOR
1405-001420	V5003,V5004	VARISTOR
1405-001422	V2007	VARISTOR
1405-001425	V1001	VARISTOR
1405-001428	V11006,V11007,V11017	VARISTOR
1405-001441	V5007	VARISTOR
1405-001450	V1000	VARISTOR
2007-000172	R5050	R-CHIP
2007-001284	R11011,R11013,R11014	R-CHIP
2007-001284	R11016	R-CHIP
2007-007100	R11009	R-CHIP
2007-007193	R9023,R9024	R-CHIP
2007-007310	R6001,R6031,R6078	R-CHIP
2007-007314	R5024,R5025	R-CHIP
2007-007698	R8020	R-CHIP
2007-007741	R10021,R4036,R5022	R-CHIP
2007-007741	R5041,R8021,R8032	R-CHIP
2007-007741	R8033,R9000,R9026	R-CHIP
2007-007942	R6043	R-CHIP
2007-007946	R6045	R-CHIP
2007-008043	R3000	R-CHIP
2007-008052	R10020,R12010	R-CHIP
2007-008211	R12004,R8041	R-CHIP
2007-008294	R9018	R-CHIP
2007-008296	R10002	R-CHIP
2007-008403	R8039	R-CHIP
2007-008419	R11008,R4028	R-CHIP
2007-008486	R10001,R8036	R-CHIP
2007-008531	R10017,R8010,R8034	R-CHIP
2007-008531	R8035,R9019	R-CHIP
2007-008774	R11010,R11012,R11015	R-CHIP
2007-008774	R11017,R5038,R5039	R-CHIP
2007-008785	R4027	R-CHIP
2007-009111	R5040	R-CHIP
2007-009157	R11006,R4017,R4018	R-CHIP
2007-009157	R5014,R6062,R6063	R-CHIP
2007-009157	R8015,R8016,R8017	R-CHIP
2007-009157	R8029,R8030	R-CHIP

5. MAIN Electrical Parts List

2007-009182	R5001,R8038	R-CHIP
2007-009201	R9007,R9008,R9010	R-CHIP
2007-009201	R9013	R-CHIP
2007-009212	R10009,R10010,R4003	R-CHIP
2007-009212	R4004,R4007,R4009	R-CHIP
2007-009212	R4010,R6023,R6024	R-CHIP
2007-009212	R6060,R6061,R8040	R-CHIP
2007-009212	R9014,R9021	R-CHIP
2007-009233	R8023,R8024	R-CHIP
2007-009314	R12007,R4026	R-CHIP
2007-009408	R12000,R9020	R-CHIP
2007-009805	R5026,R5027	R-CHIP
2007-009866	R10018,R11002,R11003	R-CHIP
2007-009866	R11004,R11005,R8001	R-CHIP
2007-009866	R8031	R-CHIP
2007-009924	R11000,R11001	R-CHIP
2007-009969	R9015	R-CHIP
2007-010202	R8009,R8012,R8013	R-CHIP
2007-010685	R8025,R8026	R-CHIP
2007-011040	R9022,R9025	R-CHIP
2007-011043	R6000	R-CHIP
2007-011378	R4000,R4001,R4008	R-CHIP
2007-011378	R5010,R5011,R6051	R-CHIP
2007-011378	R6053,R6054,R6055	R-CHIP
2007-011378	R6058,R6064,R6065	R-CHIP
2007-011378	R6066,R6067,R6068	R-CHIP
2007-011378	R6070,R6073,R6074	R-CHIP
2007-011378	R6075,R9004	R-CHIP
2007-011532	R9006	R-CHIP
2007-011542	R10003,R12003,R12005	R-CHIP
2007-011546	R6038,R6039,R6040	R-CHIP
2007-011546	R6041,R6079,R6080	R-CHIP
2007-011546	R6081,R6082	R-CHIP
2007-011548	R10004,R3002,R3003	R-CHIP
2007-011548	R3005,R3006,R6044	R-CHIP
2007-011591	R11007,R5004,R5005	R-CHIP
2007-011591	R5006,R5007,R5023	R-CHIP
2007-011591	R6002,R6003,R6006	R-CHIP
2007-011591	R6007,R6008,R6009	R-CHIP

5. MAIN Electrical Parts List

2007-011591	R6012,R6013,R6014	R-CHIP
2007-011591	R6015,R6021,R6022	R-CHIP
2007-011591	R6025,R6026,R6027	R-CHIP
2007-011591	R6028,R6029,R6030	R-CHIP
2007-011591	R6032,R6033,R6034	R-CHIP
2007-011591	R6035,R6085,R6086	R-CHIP
2007-011591	R8004,R8019	R-CHIP
2007-011594	R10007,R10008,R6010	R-CHIP
2007-011594	R6011,R6019,R6020	R-CHIP
2007-011594	R6036,R6037,R6091	R-CHIP
2007-011594	R6092	R-CHIP
2007-011599	R6042	R-CHIP
2007-011648	C4017	R-CHIP
2007-012197	R8018	R-CHIP
2007-012202	R12006	R-CHIP
2203-000138	C8181,C8183	C-CERAMIC,CHIP
2203-000233	C5067,C5074,C8117	C-CERAMIC,CHIP
2203-000330	C5071	C-CERAMIC,CHIP
2203-000438	C8174	C-CERAMIC,CHIP
2203-000489	C8150	C-CERAMIC,CHIP
2203-000679	C8127,C8128	C-CERAMIC,CHIP
2203-000725	C8173,C8180	C-CERAMIC,CHIP
2203-000812	C11008	C-CERAMIC,CHIP
2203-001033	C8124	C-CERAMIC,CHIP
2203-002285	C11010,C8103	C-CERAMIC,CHIP
2203-005682	C5037	C-CERAMIC,CHIP
2203-005725	C1051	C-CERAMIC,CHIP
2203-005726	C9033,C9035,C9036	C-CERAMIC,CHIP
2203-005726	C9044	C-CERAMIC,CHIP
2203-005727	L1044	C-CERAMIC,CHIP
2203-005731	C2025,C2060,C9053	C-CERAMIC,CHIP
2203-005731	C9054	C-CERAMIC,CHIP
2203-005732	C9047,C9051,C9052	C-CERAMIC,CHIP
2203-005732	C9060,C9061,C9062	C-CERAMIC,CHIP
2203-005734	C10020,C5082,C5083	C-CERAMIC,CHIP
2203-005734	C5087	C-CERAMIC,CHIP
2203-005736	C1001,C1003,C1005	C-CERAMIC,CHIP
2203-005736	C10078,C10079,C10089	C-CERAMIC,CHIP
2203-005736	C1009,C10090,C10091	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C10093,C10094,C10095	C-CERAMIC,CHIP
2203-005736	C1010,C1019,C1025	C-CERAMIC,CHIP
2203-005736	C1026,C1028,C1030	C-CERAMIC,CHIP
2203-005736	C1032,C1035,C1037	C-CERAMIC,CHIP
2203-005736	C1039,C1040,C1041	C-CERAMIC,CHIP
2203-005736	C1043,C1045,C1049	C-CERAMIC,CHIP
2203-005736	C1052,C1057,C1058	C-CERAMIC,CHIP
2203-005736	C1059,C1060,C1062	C-CERAMIC,CHIP
2203-005736	C1068,C1070,C1078	C-CERAMIC,CHIP
2203-005736	C1083,C1115,C2002	C-CERAMIC,CHIP
2203-005736	C2006,C2009,C2010	C-CERAMIC,CHIP
2203-005736	C2011,C2013,C2017	C-CERAMIC,CHIP
2203-005736	C2022,C2023,C2031	C-CERAMIC,CHIP
2203-005736	C2050,C2051,C2096	C-CERAMIC,CHIP
2203-005736	C2102,C2103,C3021	C-CERAMIC,CHIP
2203-005736	C5015,C5016,C5017	C-CERAMIC,CHIP
2203-005736	C5076,C5077,C5078	C-CERAMIC,CHIP
2203-005736	L1024,L1027,L1039	C-CERAMIC,CHIP
2203-005736	L1055,L2003,L5019	C-CERAMIC,CHIP
2203-005777	C1072,C1086,C2004	C-CERAMIC,CHIP
2203-005779	C10065,C10077,C10086	C-CERAMIC,CHIP
2203-005789	C1013,C1018,C1031	C-CERAMIC,CHIP
2203-005789	C1042,C1081,C1087	C-CERAMIC,CHIP
2203-005789	C2005,C2033,C2034	C-CERAMIC,CHIP
2203-005789	C2099	C-CERAMIC,CHIP
2203-005792	C5046	C-CERAMIC,CHIP
2203-005806	C5061	C-CERAMIC,CHIP
2203-006048	C5069	C-CERAMIC,CHIP
2203-006121	C1095,C9049	C-CERAMIC,CHIP
2203-006137	C12041,C5079	C-CERAMIC,CHIP
2203-006318	C1088	C-CERAMIC,CHIP
2203-006400	C3016,C3017,C3020	C-CERAMIC,CHIP
2203-006400	C5066,C5075,L3011	C-CERAMIC,CHIP
2203-006556	C1012,C8105,L1012	C-CERAMIC,CHIP
2203-006556	L1031	C-CERAMIC,CHIP
2203-006665	C5013,C5014	C-CERAMIC,CHIP
2203-006668	C4018,C6006	C-CERAMIC,CHIP
2203-006707	C2019,C2038	C-CERAMIC,CHIP
2203-006712	C1096	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006839	C1092,C1094,C1102	C-CERAMIC,CHIP
2203-006839	C1103,C5053,C8114	C-CERAMIC,CHIP
2203-006839	C8123,C8131,C8137	C-CERAMIC,CHIP
2203-006839	L1070,L1075	C-CERAMIC,CHIP
2203-006844	C11002,C11003,C11004	C-CERAMIC,CHIP
2203-006844	C11006	C-CERAMIC,CHIP
2203-006846	C2026,C2030	C-CERAMIC,CHIP
2203-006968	C1034,C2015	C-CERAMIC,CHIP
2203-006979	C3007,C3009,C4019	C-CERAMIC,CHIP
2203-007210	C4004,C7012	C-CERAMIC,CHIP
2203-007271	C1099	C-CERAMIC,CHIP
2203-007317	C4000,C4025,C5055	C-CERAMIC,CHIP
2203-007317	C5056,C7055,C7065	C-CERAMIC,CHIP
2203-007317	C7104,C7108,C7121	C-CERAMIC,CHIP
2203-007317	C9018,C9023,C9037	C-CERAMIC,CHIP
2203-007317	C9038,C9039,C9040	C-CERAMIC,CHIP
2203-007317	C9041,C9043	C-CERAMIC,CHIP
2203-007391	C10040,C3022,C9007	C-CERAMIC,CHIP
2203-007391	C9008,C9031	C-CERAMIC,CHIP
2203-007392	C1104,C1113	C-CERAMIC,CHIP
2203-007393	C10016,C10019,C10039	C-CERAMIC,CHIP
2203-007393	C10088,C1093,C12008	C-CERAMIC,CHIP
2203-007393	C12011,C5025,C5026	C-CERAMIC,CHIP
2203-007393	C5028,C5032,C5041	C-CERAMIC,CHIP
2203-007393	C5051,C5084,C5086	C-CERAMIC,CHIP
2203-007393	C8019,C8063,C8070	C-CERAMIC,CHIP
2203-007393	C8091,C8135,C8140	C-CERAMIC,CHIP
2203-007393	C8177,C9066,C9067	C-CERAMIC,CHIP
2203-007425	C8115	C-CERAMIC,CHIP
2203-007456	C9063	C-CERAMIC,CHIP
2203-007474	C10012,C10013,C4012	C-CERAMIC,CHIP
2203-007474	C8069	C-CERAMIC,CHIP
2203-007486	L9013	C-CERAMIC,CHIP
2203-007544	C8149,C8151,C8152	C-CERAMIC,CHIP
2203-007544	C8154,C8157,C8159	C-CERAMIC,CHIP
2203-007544	C8171	C-CERAMIC,CHIP
2203-007621	C10026,C10052,C11014	C-CERAMIC,CHIP
2203-007621	C2001,C2016,C2036	C-CERAMIC,CHIP
2203-007621	C3002,C3005,C3010	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007621	C3015,C3019,C4005	C-CERAMIC,CHIP
2203-007621	C4028,C4030,C5018	C-CERAMIC,CHIP
2203-007621	C5033,C5034,C5047	C-CERAMIC,CHIP
2203-007621	C5049,C5050,C5052	C-CERAMIC,CHIP
2203-007621	C5068,C6000,C6001	C-CERAMIC,CHIP
2203-007621	C8007,C8017,C8043	C-CERAMIC,CHIP
2203-007621	C8044,C8136,C8163	C-CERAMIC,CHIP
2203-007621	C9019,C9057,C9058	C-CERAMIC,CHIP
2203-007796	C10014,C10015,C1002	C-CERAMIC,CHIP
2203-007796	C10074,C1033,C11013	C-CERAMIC,CHIP
2203-007796	C12015,C12021,C12022	C-CERAMIC,CHIP
2203-007796	C12037,C12043,C3000	C-CERAMIC,CHIP
2203-007796	C3003,C3004,C3006	C-CERAMIC,CHIP
2203-007796	C3008,C3011,C3012	C-CERAMIC,CHIP
2203-007796	C3023,C3025,C4001	C-CERAMIC,CHIP
2203-007796	C5002,C5003,C5004	C-CERAMIC,CHIP
2203-007796	C5005,C5006,C5019	C-CERAMIC,CHIP
2203-007796	C5042,C5043,C5048	C-CERAMIC,CHIP
2203-007796	C5057,C5062,C5064	C-CERAMIC,CHIP
2203-007796	C7000,C7001,C7010	C-CERAMIC,CHIP
2203-007796	C7011,C7014,C7015	C-CERAMIC,CHIP
2203-007796	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007796	C7030,C7031,C7032	C-CERAMIC,CHIP
2203-007796	C7034,C7035,C7036	C-CERAMIC,CHIP
2203-007796	C7045,C7047,C7050	C-CERAMIC,CHIP
2203-007796	C7052,C7053,C7056	C-CERAMIC,CHIP
2203-007796	C7057,C7058,C7059	C-CERAMIC,CHIP
2203-007796	C7060,C7061,C7062	C-CERAMIC,CHIP
2203-007796	C7064,C7067,C7069	C-CERAMIC,CHIP
2203-007796	C7070,C7071,C7072	C-CERAMIC,CHIP
2203-007796	C7073,C7075,C7076	C-CERAMIC,CHIP
2203-007796	C7077,C7078,C7079	C-CERAMIC,CHIP
2203-007796	C7080,C7081,C7084	C-CERAMIC,CHIP
2203-007796	C7086,C7088,C7089	C-CERAMIC,CHIP
2203-007796	C7090,C7092,C7093	C-CERAMIC,CHIP
2203-007796	C7095,C7096,C7097	C-CERAMIC,CHIP
2203-007796	C7106,C7110,C7111	C-CERAMIC,CHIP
2203-007796	C7112,C7113,C7115	C-CERAMIC,CHIP
2203-007796	C7116,C7117,C7119	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-007796	C8059,C8060,C8065	C-CERAMIC,CHIP
2203-007796	C8066,C8068,C8072	C-CERAMIC,CHIP
2203-007796	C8073,C8075,C8079	C-CERAMIC,CHIP
2203-007796	C8080,C8092,C8097	C-CERAMIC,CHIP
2203-007796	C8112,C8139,C8141	C-CERAMIC,CHIP
2203-007796	C8143,C8153,C8169	C-CERAMIC,CHIP
2203-007796	C8170,C9009,C9013	C-CERAMIC,CHIP
2203-007796	C9021,C9022,C9024	C-CERAMIC,CHIP
2203-007796	C9025,C9027,C9032	C-CERAMIC,CHIP
2203-007796	C9034,C9042,C9055	C-CERAMIC,CHIP
2203-007809	C8172	C-CERAMIC,CHIP
2203-008095	C8104	C-CERAMIC,CHIP
2203-008097	C10056,C8005,C8018	C-CERAMIC,CHIP
2203-008097	C8161,C9001,C9004	C-CERAMIC,CHIP
2203-008097	C9010,C9014,C9030	C-CERAMIC,CHIP
2203-008097	R9009	C-CERAMIC,CHIP
2203-008158	C8146,C8148,C8155	C-CERAMIC,CHIP
2203-008158	C8156	C-CERAMIC,CHIP
2203-008177	C8025	C-CERAMIC,CHIP
2203-008242	C10002,C10021,C10022	C-CERAMIC,CHIP
2203-008242	C10030,C10033,C10037	C-CERAMIC,CHIP
2203-008242	C10041,C10043,C10054	C-CERAMIC,CHIP
2203-008242	C10055,C10061,C10066	C-CERAMIC,CHIP
2203-008242	C12019,C12024,C12028	C-CERAMIC,CHIP
2203-008242	C4006,C5007,C5008	C-CERAMIC,CHIP
2203-008242	C5010,C7068,C7087	C-CERAMIC,CHIP
2203-008242	C7105,C8010,C8011	C-CERAMIC,CHIP
2203-008242	C8012,C8028,C8029	C-CERAMIC,CHIP
2203-008242	C8030,C8031,C8055	C-CERAMIC,CHIP
2203-008242	C8056,C8057,C8061	C-CERAMIC,CHIP
2203-008242	C8062,C8064,C8071	C-CERAMIC,CHIP
2203-008242	C8074,C8090,C8096	C-CERAMIC,CHIP
2203-008242	C8098,C8162,C9015	C-CERAMIC,CHIP
2203-008400	L1036,R4029	C-CERAMIC,CHIP
2203-008403	C5088,C5089	C-CERAMIC,CHIP
2203-008466	C10070,C10071,C1017	C-CERAMIC,CHIP
2203-008466	C5009,C5039,C5080	C-CERAMIC,CHIP
2203-008466	C5081,C9017,R4005	C-CERAMIC,CHIP
2203-008466	R4006,R4011,R4012	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008466	R4013,R9016	C-CERAMIC,CHIP
2203-008529	C1000,C5027	C-CERAMIC,CHIP
2203-008563	C1066,C2000,C2090	C-CERAMIC,CHIP
2203-008563	C2091,C4013,C4014	C-CERAMIC,CHIP
2203-008563	C4015,C4016,C5036	C-CERAMIC,CHIP
2203-008563	C5044,C6003,C6004	C-CERAMIC,CHIP
2203-008563	C8158	C-CERAMIC,CHIP
2203-008572	C8118,C8144,C8145	C-CERAMIC,CHIP
2203-008572	C8160,C8178	C-CERAMIC,CHIP
2203-008653	C6002	C-CERAMIC,CHIP
2203-008749	C9064	C-CERAMIC,CHIP
2203-008844	C10011	C-CERAMIC,CHIP
2203-008860	C1069,C1114,C12012	C-CERAMIC,CHIP
2203-008860	C12029,C12036,C12039	C-CERAMIC,CHIP
2203-008860	C3001,C8134,C8179	C-CERAMIC,CHIP
2203-008876	C10001,C10004,C10007	C-CERAMIC,CHIP
2203-008876	C10008,C10009,C10023	C-CERAMIC,CHIP
2203-008876	C10024,C10025,C10031	C-CERAMIC,CHIP
2203-008876	C10032,C10036,C10038	C-CERAMIC,CHIP
2203-008876	C10053,C10062,C10063	C-CERAMIC,CHIP
2203-008876	C10069,C10080,C10097	C-CERAMIC,CHIP
2203-008876	C10098,C10107,C1067	C-CERAMIC,CHIP
2203-008876	C12018,C12023,C12027	C-CERAMIC,CHIP
2203-008876	C12030,C12031,C4011	C-CERAMIC,CHIP
2203-008876	C8004,C8006,C8008	C-CERAMIC,CHIP
2203-008876	C8009,C8013,C8014	C-CERAMIC,CHIP
2203-008876	C8016,C8020,C8021	C-CERAMIC,CHIP
2203-008876	C8032,C8037,C8038	C-CERAMIC,CHIP
2203-008876	C8041,C8042,C8045	C-CERAMIC,CHIP
2203-008876	C8047,C8050,C8051	C-CERAMIC,CHIP
2203-008876	C8052,C8053,C8067	C-CERAMIC,CHIP
2203-008876	C8089,C8100,C8102	C-CERAMIC,CHIP
2203-008876	C8113,C8164,C9026	C-CERAMIC,CHIP
2203-008876	C9028,C9045,R10005	C-CERAMIC,CHIP
2203-008886	C11005,C11007	C-CERAMIC,CHIP
2203-008886	ZD11000,ZD11001	C-CERAMIC,CHIP
2203-009025	C2024	C-CERAMIC,CHIP
2203-009064	C7002,C7003,C7005	C-CERAMIC,CHIP
2203-009064	C7007,C7008,C7018	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009064	C7019,C7020,C7022	C-CERAMIC,CHIP
2203-009064	C7051,C7114	C-CERAMIC,CHIP
2203-009167	C5070,C5073	C-CERAMIC,CHIP
2203-009220	C11012	C-CERAMIC,CHIP
2203-009444	C8106	C-CERAMIC,CHIP
2203-009537	C12016,C12017,C7048	C-CERAMIC,CHIP
2203-009551	C12035	C-CERAMIC,CHIP
2203-009618	C10010,C12001,C12002	C-CERAMIC,CHIP
2203-009618	C12003,C12004,C12005	C-CERAMIC,CHIP
2203-009618	C5040	C-CERAMIC,CHIP
2203-009733	C10003,C10005,C10017	C-CERAMIC,CHIP
2203-009733	C10044,C10085,C10087	C-CERAMIC,CHIP
2203-009733	C1105,C1106,C12006	C-CERAMIC,CHIP
2203-009733	C12007,C12044,C8022	C-CERAMIC,CHIP
2203-009733	C8088,C9012,C9016	C-CERAMIC,CHIP
2203-009735	C7098,C7102	C-CERAMIC,CHIP
2203-009736	C10027,C10029,C10048	C-CERAMIC,CHIP
2203-009736	C10049,C10051,C10075	C-CERAMIC,CHIP
2203-009736	C10076,C10081,C10082	C-CERAMIC,CHIP
2203-009736	C10083,C10084,C10092	C-CERAMIC,CHIP
2203-009736	C10099,C10100,C10101	C-CERAMIC,CHIP
2203-009736	C10102,C10103,C10104	C-CERAMIC,CHIP
2203-009736	C10105,C10106,C3014	C-CERAMIC,CHIP
2203-009736	C3018,C9020	C-CERAMIC,CHIP
2203-009812	C8119	C-CERAMIC,CHIP
2203-009858	C4002,C4010,C5059	C-CERAMIC,CHIP
2203-009858	C5060,C5065,C8000	C-CERAMIC,CHIP
2203-009858	C8001,C8002,C8003	C-CERAMIC,CHIP
2203-009858	C8125,C8126,C8129	C-CERAMIC,CHIP
2203-009858	C8138	C-CERAMIC,CHIP
2203-009859	C12000,C12013,C12014	C-CERAMIC,CHIP
2203-009969	C9000,C9002,C9003	C-CERAMIC,CHIP
2203-009969	C9005	C-CERAMIC,CHIP
2203-009987	C10028,C10045,C10046	C-CERAMIC,CHIP
2203-009987	C10047,C4008,C4009	C-CERAMIC,CHIP
2203-009987	C8085,C8086,C8087	C-CERAMIC,CHIP
2203-010085	C8040,C8081,C8082	C-CERAMIC,CHIP
2203-010085	C8083,C8084,L8018	C-CERAMIC,CHIP
2409-001387	TA8006,TA8007	CAPACITOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2409-001400	TA8000,TA8001,TA8002	CAPACITOR
2409-001400	TA8003,TA8004,TA8005	CAPACITOR
2703-002170	L1015	INDUCTOR
2703-002901	L1021	INDUCTOR
2703-002955	C2008,L1014	INDUCTOR
2703-002958	L1037,L1065,L2005	INDUCTOR
2703-002958	L2010,L2013,L2014	INDUCTOR
2703-002958	L2015,L2018,L2031	INDUCTOR
2703-002958	L2033	INDUCTOR
2703-002959	L10008,L10015,L10016	INDUCTOR
2703-002961	L1020	INDUCTOR
2703-002999	L1010,L2030	INDUCTOR
2703-003479	L2017	INDUCTOR
2703-004012	C1023,C1029,L1002	INDUCTOR
2703-004012	L1023,L1033,L1042	INDUCTOR
2703-004012	L1048,L1051,L1052	INDUCTOR
2703-004012	L2026,L2032,L2042	INDUCTOR
2703-004013	C2014,L1004,L1076	INDUCTOR
2703-004013	L2016,L5012	INDUCTOR
2703-004014	C1047,C1076,C2049	INDUCTOR
2703-004014	C5020,C5029,L1026	INDUCTOR
2703-004014	L1050,L2037	INDUCTOR
2703-004018	C1027,L1064,L5040	INDUCTOR
2703-004034	C2018,C2027,L1058	INDUCTOR
2703-004034	L2021,L2027,L2043	INDUCTOR
2703-004034	L2057	INDUCTOR
2703-004036	C2007,L2006	INDUCTOR
2703-004038	C1050,C1079,L1000	INDUCTOR
2703-004038	L1038,L1045	INDUCTOR
2703-004287	L1040	INDUCTOR
2703-004300	C2012,C5021,L2028	INDUCTOR
2703-004300	L2045,L5025	INDUCTOR
2703-004363	L2038	INDUCTOR
2703-004371	C1084	INDUCTOR
2703-004703	L1005,L1006,L1029	INDUCTOR
2703-004703	L1053,L1062,L5052	INDUCTOR
2703-004703	L5055,L5057	INDUCTOR
2703-004853	L1019,L11000	INDUCTOR
2703-005058	L4001	INDUCTOR

5. MAIN Electrical Parts List

2703-005067	L10001,L10002,L10003	INDUCTOR
2703-005067	L12007,L5039	INDUCTOR
2703-005085	C1046,C1061,C1085	INDUCTOR
2703-005085	C2020,C2035,C2039	INDUCTOR
2703-005085	L1025,L1032,L1035	INDUCTOR
2703-005085	L1043,L1063,L5024	INDUCTOR
2703-005086	C1071,C1074,C2028	INDUCTOR
2703-005086	L1049,L1054,L1056	INDUCTOR
2703-005086	L5008,L5018	INDUCTOR
2703-005087	L2025,L2036,L5041	INDUCTOR
2703-005088	L1041	INDUCTOR
2703-005089	L1028,L5050	INDUCTOR
2703-005200	L5033,L5035	INDUCTOR
2703-005201	L8001,L8003,L8004	INDUCTOR
2703-005201	L8005,L8008,L8009	INDUCTOR
2703-005201	L8010,L8011,L8017	INDUCTOR
2703-005201	L8026	INDUCTOR
2703-005224	L12000	INDUCTOR
2703-005225	L10000,L4000,L8027	INDUCTOR
2703-005233	L8024,L8025,L9000	INDUCTOR
2703-005233	L9001,L9005,L9007	INDUCTOR
2703-005295	L1008,L1013,L5014	INDUCTOR
2703-005296	L2009	INDUCTOR
2703-005418	L12006	INDUCTOR
2703-005430	L1072	INDUCTOR
2703-005505	L1074,L9002,L9003	INDUCTOR
2703-005509	L8002,L8006,L8007	INDUCTOR
2703-005509	L8012,L8013,L8014	INDUCTOR
2703-005509	L8015,L8016,L8022	INDUCTOR
2703-005555	L5047,L5048	INDUCTOR
2703-005614	L1022,L1059,L5042	INDUCTOR
2703-005660	L8023	INDUCTOR
2703-005663	L12003,L12004	INDUCTOR
2801-005393	OSC8000	CRYSTAL-UNIT
2805-001118	OSC5000	OSCILLATOR
2805-001128	TCX4000	OSCILLATOR
2901-001690	C7004,C7006,C7017	FILTER
2901-001690	C7021,C7037,C7038	FILTER
2901-001690	C7039,C7040,C7049	FILTER

5. MAIN Electrical Parts List

2901-001690	C7054,C7063,C7094	FILTER
2901-001690	C7099,C7100,C7101	FILTER
2901-001690	C7103,C7107	FILTER
2903-001576	F5001	FILTER
2904-002270	F2007	FILTER
2904-002296	F1001	FILTER
2904-002356	F5008	FILTER
2904-002362	C1077,F2005	FILTER
2904-002378	F2002	FILTER
2904-002393	F5005	FILTER
2904-002397	F2003	FILTER
2904-002401	F5003	FILTER
2904-002403	F1002	FILTER
2909-001422	F5006	FILTER
2911-000453	F2000	FILTER
2911-000455	F2004,U2000	FILTER
3003-001243	AU9000	MIC-CONDENSOR
3003-001253	MIC9000	MIC-CONDENSOR
3301-001885	L9006	CORE-FERRITE BEAD
3301-001989	L12009	CORE-FERRITE BEAD
3301-002223	L10004,L10007,L10010	CORE-FERRITE BEAD
3301-002223	L10012,L10013,L10014	CORE-FERRITE BEAD
3301-002228	L9004	CORE-FERRITE BEAD
3301-002235	L11001,L11002,L5045	CORE-FERRITE BEAD
3301-002235	L5046	CORE-FERRITE BEAD
3301-002237	L1001,L1009,L1011	CORE-FERRITE BEAD
3301-002237	L1034,L2001,L2002	CORE-FERRITE BEAD
3301-002237	L2007,L2011,L2012	CORE-FERRITE BEAD
3301-002237	L5038,L9011,R5000	CORE-FERRITE BEAD
3301-002238	L12008,L5060	CORE-FERRITE BEAD
3301-002239	L1016,L12010,L8030	CORE-FERRITE BEAD
3301-002243	L1007	CORE-FERRITE BEAD
3301-002244	L1073	CORE-FERRITE BEAD
3301-002279	L10017,L10018,L10019	CORE-FERRITE BEAD
3301-002312	L1069,L12001,L12002	CORE-FERRITE BEAD
3301-002312	L12005,L4002,L5029	CORE-FERRITE BEAD
3301-002312	L5058,L5059	CORE-FERRITE BEAD
3301-002331	L8020,L8021,L9010	CORE-FERRITE BEAD
3301-002375	L9008,L9009	CORE-FERRITE BEAD

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

3705-001708	RFS100,RFS1001	CONNECTOR-COAXIAL
3709-001892	CN4000	CONNECTOR-CARD EDGE
3711-008847	HDC8000	CONNECTOR-HEADER
3711-008997	HEA9000	CONNECTOR-HEADER
3711-009356	HEA10001	CONNECTOR-HEADER
3711-009359	HEA10003,HEA12000	CONNECTOR-HEADER
3711-009407	HEA10002	CONNECTOR-HEADER
3712-001604	ANT1003,ANT1005	CONNECTOR
3712-001604	ANT1006,ANT1007	CONNECTOR
3712-001604	ANT1008,ANT1010	CONNECTOR
3712-001604	ANT1011,ANT8000	CONNECTOR
3712-001604	ANT8001,ANT8002	CONNECTOR
3712-001604	ANT8003,ANT8004	CONNECTOR
3712-001604	ANT8005,ANT8006	CONNECTOR
3712-001633	ANT8007,ANT8008	CONNECTOR
3712-001634	ANT4000,ANT4001	CONNECTOR
3712-001634	ANT4002,ANT4003	CONNECTOR
3712-001634	ANT4004,ANT4005	CONNECTOR
3712-001666	ANT1002,ANT1004	CONNECTOR
3712-001666	ANT5003,ANT5004	CONNECTOR
3712-001666	ANT9002,ANT9003	CONNECTOR
3712-001666	SANT2002,SANT2008	CONNECTOR
3712-001694	ANT1012,ANT11000	CONNECTOR
3712-001694	ANT11001,ANT11002	CONNECTOR
3712-001694	ANT11003,ANT11004	CONNECTOR
3712-001694	ANT11005,ANT11006	CONNECTOR
3712-001694	ANT11007,ANT11008	CONNECTOR
3712-001694	ANT5000,ANT5001	CONNECTOR
3712-001694	ANT5002,ANT5005	CONNECTOR
3712-001694	SANT2000,SANT2001	CONNECTOR
3712-001694	SANT2005,SANT2006	CONNECTOR
3712-001694	SANT2007	CONNECTOR
3712-001714	ANT9000,ANT9001	CONNECTOR
3712-001731	ANT1001,SANT2003	CONNECTOR
3712-001731	SANT2004	CONNECTOR
3722-004150	USB11000	JACK-PHONE
4709-002196	F1000	RF-MODULE
4709-002285	F5004	RF-MODULE
4709-002716	U5003	RF-MODULE

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

[SM-G975FC]

Parts Code	Design LOC	Description
0401-001110	ZD8009	DIODE-SWITCHING
0404-001250	D8000,D9000	DIODE-SCHOTTKY
0406-001561	ZD9012	DIODE-TVS
0406-001709	ZD9009	DIODE-TVS
0406-001729	ZD8007,ZD8008	DIODE-TVS
0406-001781	ZD9007,ZD9011	DIODE-TVS
0406-001787	V9000,V9001,ZD11008	DIODE-TVS
0406-001787	ZD11019,ZD9000	DIODE-TVS
0406-001787	ZD9001	DIODE-TVS
0406-001804	ZD11006,ZD11007	DIODE-TVS
0406-001804	ZD11009,ZD11010	DIODE-TVS
0406-001804	ZD11017,ZD11018	DIODE-TVS
0406-001804	ZD11020,ZD11021	DIODE-TVS
0406-001805	ZD8003	DIODE-TVS
0406-001809	ZD11011,ZD11012	DIODE-TVS
0406-001826	ZD11002,ZD11022	DIODE-TVS
0601-003707	LED10000	LED
0801-003639	U8001	IC
0903-002233	U10003	IC
1001-001755	U9001	IC
1001-001975	U1003	IC
1001-002045	U8025	IC
1001-002075	F2001,U1002,U1004	IC
1009-001076	U11001,U5009	IC
1107-002651	UME4000	IC
1201-003735	U5007	IC
1201-004114	PAM1001	IC
1201-004157	PAM1000	IC
1201-004178	U9003,ZD9003	IC
1201-004210	U1005	IC
1202-001120	U12001	IC
1203-008472	U10002	IC
1203-008729	U4000	IC
1203-008802	U8008	IC
1203-008811	U5008	IC
1203-008867	U12002,U5006,U8035	IC
1203-009032	U12000	IC

5. MAIN Electrical Parts List

1203-009035	U10001	IC
1203-009080	U9002	IC
1203-009156	U8031	IC
1203-009168	U8003	IC
1203-009187	U8015	IC
1203-009191	U12003	IC
1204-003761	L1071	IC
1204-003773	U1001	IC
1205-005217	U10004	IC
1205-005729	U9000	IC
1205-005871	U5014	IC
1205-005880	U5002	IC
1205-006032	U3000	IC
1205-006044	UCP5000	IC
1209-002513	U5013	IC
1209-002558	U5011	IC
1209-002567	U5012	IC
1209-002578	U5010	IC
1209-002607	U11000	IC
1209-002608	U5004	IC
1209-002619	U5005	IC
1404-001724	TH11000,TH5000	THERMISTOR
1404-001724	TH6000,TH8000,TH8001	THERMISTOR
1404-001724	TH8002,V4000	THERMISTOR
1405-001395	V11003,V11010,V11011	VARISTOR
1405-001395	V11012,V11013,V11014	VARISTOR
1405-001395	V11018,V11019,V11020	VARISTOR
1405-001395	V11021,V2001,V2004	VARISTOR
1405-001403	V11024,V2003	VARISTOR
1405-001404	V11000,V11001,V11009	VARISTOR
1405-001404	V11015,V11026,V11027	VARISTOR
1405-001404	V11029,V2010,V2011	VARISTOR
1405-001404	V5012	VARISTOR
1405-001412	V1002	VARISTOR
1405-001415	V1003,V11023,V11025	VARISTOR
1405-001415	V11030,V11031,V2002	VARISTOR
1405-001415	V2008,V2009,V5005	VARISTOR
1405-001415	V5006	VARISTOR
1405-001420	R1003,V11002,V11004	VARISTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

1405-001420	V11005,V11008,V11022	VARISTOR
1405-001420	V11028,V2000,V5002	VARISTOR
1405-001420	V5003,V5004	VARISTOR
1405-001422	V2007	VARISTOR
1405-001425	V1001	VARISTOR
1405-001428	V11006,V11007,V11017	VARISTOR
1405-001441	V5007	VARISTOR
1405-001450	V1000	VARISTOR
2007-000172	R5050	R-CHIP
2007-001284	R11011,R11013,R11014	R-CHIP
2007-001284	R11016	R-CHIP
2007-007100	R11009	R-CHIP
2007-007193	R9023,R9024	R-CHIP
2007-007310	R6001,R6031,R6078	R-CHIP
2007-007314	R5024,R5025	R-CHIP
2007-007698	R8020	R-CHIP
2007-007741	R10021,R4035,R5022	R-CHIP
2007-007741	R5041,R8021,R8032	R-CHIP
2007-007741	R8033,R9000,R9026	R-CHIP
2007-007942	R6043	R-CHIP
2007-007946	R6045	R-CHIP
2007-008043	R3000	R-CHIP
2007-008052	R10020,R12010	R-CHIP
2007-008211	R12004,R8041	R-CHIP
2007-008294	R9018	R-CHIP
2007-008296	R10002	R-CHIP
2007-008403	R8039	R-CHIP
2007-008419	R11008,R4028	R-CHIP
2007-008486	R10001,R8036	R-CHIP
2007-008531	R10017,R8010,R8034	R-CHIP
2007-008531	R8035,R9019	R-CHIP
2007-008774	R11010,R11012,R11015	R-CHIP
2007-008774	R11017,R5038,R5039	R-CHIP
2007-008785	R4027	R-CHIP
2007-009111	R5040	R-CHIP
2007-009157	R11006,R4017,R4018	R-CHIP
2007-009157	R5014,R6062,R6063	R-CHIP
2007-009157	R8015,R8016,R8017	R-CHIP
2007-009157	R8029,R8030	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-009182	R5001,R8038	R-CHIP
2007-009201	R9007,R9008,R9010	R-CHIP
2007-009201	R9013	R-CHIP
2007-009212	R10009,R10010,R4003	R-CHIP
2007-009212	R4004,R4007,R4009	R-CHIP
2007-009212	R4010,R6023,R6024	R-CHIP
2007-009212	R6060,R6061,R8040	R-CHIP
2007-009212	R9014,R9021	R-CHIP
2007-009233	R8023,R8024	R-CHIP
2007-009314	R12007,R4026	R-CHIP
2007-009408	R12000,R9020	R-CHIP
2007-009805	R5026,R5027	R-CHIP
2007-009866	R10018,R11002,R11003	R-CHIP
2007-009866	R11004,R11005,R8001	R-CHIP
2007-009866	R8031	R-CHIP
2007-009924	R11000,R11001	R-CHIP
2007-009969	R9015	R-CHIP
2007-010202	R8009,R8012,R8013	R-CHIP
2007-010685	R8025,R8026	R-CHIP
2007-011040	R9022,R9025	R-CHIP
2007-011043	R6000	R-CHIP
2007-011378	R4000,R4001,R4008	R-CHIP
2007-011378	R5010,R5011,R6051	R-CHIP
2007-011378	R6053,R6054,R6055	R-CHIP
2007-011378	R6058,R6064,R6065	R-CHIP
2007-011378	R6066,R6067,R6068	R-CHIP
2007-011378	R6070,R6073,R6074	R-CHIP
2007-011378	R6075,R9004	R-CHIP
2007-011532	R9006	R-CHIP
2007-011542	R10003,R12003,R12005	R-CHIP
2007-011546	R6038,R6039,R6040	R-CHIP
2007-011546	R6041,R6079,R6080	R-CHIP
2007-011546	R6081,R6082	R-CHIP
2007-011548	R10004,R3002,R3003	R-CHIP
2007-011548	R3005,R3006,R6044	R-CHIP
2007-011591	R11007,R5004,R5005	R-CHIP
2007-011591	R5006,R5007,R5023	R-CHIP
2007-011591	R6002,R6003,R6006	R-CHIP
2007-011591	R6007,R6008,R6009	R-CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2007-011591	R6012,R6013,R6014	R-CHIP
2007-011591	R6015,R6021,R6022	R-CHIP
2007-011591	R6025,R6026,R6027	R-CHIP
2007-011591	R6028,R6029,R6030	R-CHIP
2007-011591	R6032,R6033,R6034	R-CHIP
2007-011591	R6035,R6085,R6086	R-CHIP
2007-011591	R8004,R8019	R-CHIP
2007-011594	R10007,R10008,R6010	R-CHIP
2007-011594	R6011,R6019,R6020	R-CHIP
2007-011594	R6036,R6037,R6091	R-CHIP
2007-011594	R6092	R-CHIP
2007-011599	R6042	R-CHIP
2007-011648	C4017	R-CHIP
2007-012197	R8018	R-CHIP
2007-012202	R12006	R-CHIP
2203-000138	C8181,C8183	C-CERAMIC,CHIP
2203-000233	C5067,C5074,C8117	C-CERAMIC,CHIP
2203-000330	C5071	C-CERAMIC,CHIP
2203-000438	C8174	C-CERAMIC,CHIP
2203-000489	C8150	C-CERAMIC,CHIP
2203-000679	C8127,C8128	C-CERAMIC,CHIP
2203-000725	C8173,C8180	C-CERAMIC,CHIP
2203-000812	C11008	C-CERAMIC,CHIP
2203-001033	C8124	C-CERAMIC,CHIP
2203-002285	C11010,C8103	C-CERAMIC,CHIP
2203-005682	C5037	C-CERAMIC,CHIP
2203-005725	C1051	C-CERAMIC,CHIP
2203-005726	C9033,C9035,C9036	C-CERAMIC,CHIP
2203-005726	C9044	C-CERAMIC,CHIP
2203-005727	L1044	C-CERAMIC,CHIP
2203-005731	C2025,C2060,C9053	C-CERAMIC,CHIP
2203-005731	C9054	C-CERAMIC,CHIP
2203-005732	C9047,C9051,C9052	C-CERAMIC,CHIP
2203-005732	C9060,C9061,C9062	C-CERAMIC,CHIP
2203-005734	C10020,C5082,C5083	C-CERAMIC,CHIP
2203-005734	C5087	C-CERAMIC,CHIP
2203-005736	C1001,C1003,C1005	C-CERAMIC,CHIP
2203-005736	C10078,C10079,C10089	C-CERAMIC,CHIP
2203-005736	C1009,C10090,C10091	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-005736	C10093,C10094,C10095	C-CERAMIC,CHIP
2203-005736	C1010,C1019,C1023	C-CERAMIC,CHIP
2203-005736	C1025,C1026,C1028	C-CERAMIC,CHIP
2203-005736	C1030,C1032,C1035	C-CERAMIC,CHIP
2203-005736	C1037,C1039,C1040	C-CERAMIC,CHIP
2203-005736	C1041,C1043,C1045	C-CERAMIC,CHIP
2203-005736	C1052,C1057,C1058	C-CERAMIC,CHIP
2203-005736	C1059,C1060,C1062	C-CERAMIC,CHIP
2203-005736	C1068,C1070,C1078	C-CERAMIC,CHIP
2203-005736	C1083,C1115,C2002	C-CERAMIC,CHIP
2203-005736	C2006,C2009,C2010	C-CERAMIC,CHIP
2203-005736	C2011,C2013,C2017	C-CERAMIC,CHIP
2203-005736	C2022,C2023,C2031	C-CERAMIC,CHIP
2203-005736	C2050,C2051,C2096	C-CERAMIC,CHIP
2203-005736	C2102,C2103,C3021	C-CERAMIC,CHIP
2203-005736	C5015,C5016,C5017	C-CERAMIC,CHIP
2203-005736	C5076,C5077,C5078	C-CERAMIC,CHIP
2203-005736	L1002,L1024,L1027	C-CERAMIC,CHIP
2203-005736	L1039,L1055,L2003	C-CERAMIC,CHIP
2203-005736	L5019	C-CERAMIC,CHIP
2203-005736	L1025	C-CERAMIC,CHIP
2203-005777	C1072,C1086	C-CERAMIC,CHIP
2203-005779	C10065,C10077,C10086	C-CERAMIC,CHIP
2203-005789	C1013,C1018,C1031	C-CERAMIC,CHIP
2203-005789	C1042,C1081,C1087	C-CERAMIC,CHIP
2203-005789	C2005,C2033,C2034	C-CERAMIC,CHIP
2203-005789	C2099	C-CERAMIC,CHIP
2203-005792	C5046	C-CERAMIC,CHIP
2203-005806	C5061	C-CERAMIC,CHIP
2203-006048	C5069	C-CERAMIC,CHIP
2203-006121	C1095,C9049	C-CERAMIC,CHIP
2203-006137	C12041,C5079	C-CERAMIC,CHIP
2203-006318	C1088	C-CERAMIC,CHIP
2203-006400	C3016,C3017,C3020	C-CERAMIC,CHIP
2203-006400	C5066,C5075,L3011	C-CERAMIC,CHIP
2203-006556	C1012,C8105,L1012	C-CERAMIC,CHIP
2203-006556	L1031	C-CERAMIC,CHIP
2203-006665	C5013,C5014	C-CERAMIC,CHIP
2203-006668	C4018,C6006	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-006707	C2019,C2038	C-CERAMIC,CHIP
2203-006712	C1096	C-CERAMIC,CHIP
2203-006839	C1092,C1094,C1102	C-CERAMIC,CHIP
2203-006839	C1103,C5053,C8114	C-CERAMIC,CHIP
2203-006839	C8123,C8131,C8137	C-CERAMIC,CHIP
2203-006839	L1070,L1075	C-CERAMIC,CHIP
2203-006844	C11002,C11003,C11004	C-CERAMIC,CHIP
2203-006844	C11006	C-CERAMIC,CHIP
2203-006846	C2026,C2030	C-CERAMIC,CHIP
2203-006968	C1034,C2015	C-CERAMIC,CHIP
2203-006979	C3007,C3009,C4019	C-CERAMIC,CHIP
2203-007210	C4004,C7012	C-CERAMIC,CHIP
2203-007271	C1099	C-CERAMIC,CHIP
2203-007317	C4000,C4025,C5055	C-CERAMIC,CHIP
2203-007317	C5056,C7055,C7065	C-CERAMIC,CHIP
2203-007317	C7104,C7108,C7121	C-CERAMIC,CHIP
2203-007317	C9018,C9023,C9037	C-CERAMIC,CHIP
2203-007317	C9038,C9039,C9040	C-CERAMIC,CHIP
2203-007317	C9041,C9043	C-CERAMIC,CHIP
2203-007391	C10040,C3022,C9007	C-CERAMIC,CHIP
2203-007391	C9008,C9031	C-CERAMIC,CHIP
2203-007392	C1104,C1113	C-CERAMIC,CHIP
2203-007393	C10016,C10019,C10039	C-CERAMIC,CHIP
2203-007393	C10088,C1093,C12008	C-CERAMIC,CHIP
2203-007393	C12011,C5025,C5026	C-CERAMIC,CHIP
2203-007393	C5028,C5032,C5041	C-CERAMIC,CHIP
2203-007393	C5051,C5084,C5086	C-CERAMIC,CHIP
2203-007393	C8019,C8063,C8070	C-CERAMIC,CHIP
2203-007393	C8091,C8135,C8140	C-CERAMIC,CHIP
2203-007393	C8177,C9066,C9067	C-CERAMIC,CHIP
2203-007425	C8115	C-CERAMIC,CHIP
2203-007456	C9063	C-CERAMIC,CHIP
2203-007474	C10012,C10013,C4012	C-CERAMIC,CHIP
2203-007474	C8069	C-CERAMIC,CHIP
2203-007486	L9013	C-CERAMIC,CHIP
2203-007544	C8149,C8151,C8152	C-CERAMIC,CHIP
2203-007544	C8154,C8157,C8159	C-CERAMIC,CHIP
2203-007544	C8171	C-CERAMIC,CHIP
2203-007621	C10026,C10052,C11014	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007621	C2001,C2016,C2036	C-CERAMIC,CHIP
2203-007621	C3002,C3005,C3010	C-CERAMIC,CHIP
2203-007621	C3015,C3019,C4005	C-CERAMIC,CHIP
2203-007621	C4028,C4030,C5018	C-CERAMIC,CHIP
2203-007621	C5033,C5034,C5047	C-CERAMIC,CHIP
2203-007621	C5049,C5050,C5052	C-CERAMIC,CHIP
2203-007621	C5068,C6000,C6001	C-CERAMIC,CHIP
2203-007621	C8007,C8017,C8043	C-CERAMIC,CHIP
2203-007621	C8044,C8136,C8163	C-CERAMIC,CHIP
2203-007621	C9019,C9057,C9058	C-CERAMIC,CHIP
2203-007796	C10014,C10015,C1002	C-CERAMIC,CHIP
2203-007796	C10074,C1033,C11013	C-CERAMIC,CHIP
2203-007796	C12015,C12021,C12022	C-CERAMIC,CHIP
2203-007796	C12037,C12043,C3000	C-CERAMIC,CHIP
2203-007796	C3003,C3004,C3006	C-CERAMIC,CHIP
2203-007796	C3008,C3011,C3012	C-CERAMIC,CHIP
2203-007796	C3023,C3025,C4001	C-CERAMIC,CHIP
2203-007796	C5002,C5003,C5004	C-CERAMIC,CHIP
2203-007796	C5005,C5006,C5019	C-CERAMIC,CHIP
2203-007796	C5042,C5043,C5048	C-CERAMIC,CHIP
2203-007796	C5057,C5062,C5064	C-CERAMIC,CHIP
2203-007796	C7000,C7001,C7010	C-CERAMIC,CHIP
2203-007796	C7011,C7014,C7015	C-CERAMIC,CHIP
2203-007796	C7024,C7027,C7028	C-CERAMIC,CHIP
2203-007796	C7030,C7031,C7032	C-CERAMIC,CHIP
2203-007796	C7034,C7035,C7036	C-CERAMIC,CHIP
2203-007796	C7045,C7047,C7050	C-CERAMIC,CHIP
2203-007796	C7052,C7053,C7056	C-CERAMIC,CHIP
2203-007796	C7057,C7058,C7059	C-CERAMIC,CHIP
2203-007796	C7060,C7061,C7062	C-CERAMIC,CHIP
2203-007796	C7064,C7067,C7069	C-CERAMIC,CHIP
2203-007796	C7070,C7071,C7072	C-CERAMIC,CHIP
2203-007796	C7073,C7075,C7076	C-CERAMIC,CHIP
2203-007796	C7077,C7078,C7079	C-CERAMIC,CHIP
2203-007796	C7080,C7081,C7084	C-CERAMIC,CHIP
2203-007796	C7086,C7088,C7089	C-CERAMIC,CHIP
2203-007796	C7090,C7092,C7093	C-CERAMIC,CHIP
2203-007796	C7095,C7096,C7097	C-CERAMIC,CHIP
2203-007796	C7106,C7110,C7111	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-007796	C7112,C7113,C7115	C-CERAMIC,CHIP
2203-007796	C7116,C7117,C7119	C-CERAMIC,CHIP
2203-007796	C8059,C8060,C8065	C-CERAMIC,CHIP
2203-007796	C8066,C8068,C8072	C-CERAMIC,CHIP
2203-007796	C8073,C8075,C8079	C-CERAMIC,CHIP
2203-007796	C8080,C8092,C8097	C-CERAMIC,CHIP
2203-007796	C8112,C8139,C8141	C-CERAMIC,CHIP
2203-007796	C8143,C8153,C8169	C-CERAMIC,CHIP
2203-007796	C8170,C9009,C9013	C-CERAMIC,CHIP
2203-007796	C9021,C9022,C9024	C-CERAMIC,CHIP
2203-007796	C9025,C9027,C9032	C-CERAMIC,CHIP
2203-007796	C9034,C9042,C9055	C-CERAMIC,CHIP
2203-007809	C8172	C-CERAMIC,CHIP
2203-008095	C8104	C-CERAMIC,CHIP
2203-008097	C10056,C8005,C8018	C-CERAMIC,CHIP
2203-008097	C8161,C9001,C9004	C-CERAMIC,CHIP
2203-008097	C9010,C9014,C9030	C-CERAMIC,CHIP
2203-008097	R9009	C-CERAMIC,CHIP
2203-008158	C8146,C8148,C8155	C-CERAMIC,CHIP
2203-008158	C8156	C-CERAMIC,CHIP
2203-008177	C8025	C-CERAMIC,CHIP
2203-008242	C10002,C10021,C10022	C-CERAMIC,CHIP
2203-008242	C10030,C10033,C10037	C-CERAMIC,CHIP
2203-008242	C10041,C10043,C10054	C-CERAMIC,CHIP
2203-008242	C10055,C10061,C10066	C-CERAMIC,CHIP
2203-008242	C12019,C12024,C12028	C-CERAMIC,CHIP
2203-008242	C4006,C5007,C5008	C-CERAMIC,CHIP
2203-008242	C5010,C7068,C7087	C-CERAMIC,CHIP
2203-008242	C7105,C8010,C8011	C-CERAMIC,CHIP
2203-008242	C8012,C8028,C8029	C-CERAMIC,CHIP
2203-008242	C8030,C8031,C8055	C-CERAMIC,CHIP
2203-008242	C8056,C8057,C8061	C-CERAMIC,CHIP
2203-008242	C8062,C8064,C8071	C-CERAMIC,CHIP
2203-008242	C8074,C8090,C8096	C-CERAMIC,CHIP
2203-008242	C8098,C8162,C9015	C-CERAMIC,CHIP
2203-008400	L1036,R4029	C-CERAMIC,CHIP
2203-008403	C5088,C5089	C-CERAMIC,CHIP
2203-008466	C10070,C10071,C1017	C-CERAMIC,CHIP
2203-008466	C5009,C5039,C5080	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-008466	C5081,C9017,R4005	C-CERAMIC,CHIP
2203-008466	R4006,R4011,R4012	C-CERAMIC,CHIP
2203-008466	R4013,R9016	C-CERAMIC,CHIP
2203-008529	C1000,C5027	C-CERAMIC,CHIP
2203-008563	C1066,C2000,C2090	C-CERAMIC,CHIP
2203-008563	C2091,C4013,C4014	C-CERAMIC,CHIP
2203-008563	C4015,C4016,C5036	C-CERAMIC,CHIP
2203-008563	C5044,C6003,C6004	C-CERAMIC,CHIP
2203-008563	C8158	C-CERAMIC,CHIP
2203-008572	C8118,C8144,C8145	C-CERAMIC,CHIP
2203-008572	C8160,C8178	C-CERAMIC,CHIP
2203-008653	C6002	C-CERAMIC,CHIP
2203-008749	C9064	C-CERAMIC,CHIP
2203-008844	C10011	C-CERAMIC,CHIP
2203-008860	C1069,C1114,C12012	C-CERAMIC,CHIP
2203-008860	C12029,C12036,C12039	C-CERAMIC,CHIP
2203-008860	C3001,C8134,C8179	C-CERAMIC,CHIP
2203-008876	C10001,C10004,C10007	C-CERAMIC,CHIP
2203-008876	C10008,C10009,C10023	C-CERAMIC,CHIP
2203-008876	C10024,C10025,C10031	C-CERAMIC,CHIP
2203-008876	C10032,C10036,C10038	C-CERAMIC,CHIP
2203-008876	C10053,C10062,C10063	C-CERAMIC,CHIP
2203-008876	C10069,C10080,C10097	C-CERAMIC,CHIP
2203-008876	C10098,C10107,C1067	C-CERAMIC,CHIP
2203-008876	C12018,C12023,C12027	C-CERAMIC,CHIP
2203-008876	C12030,C12031,C4011	C-CERAMIC,CHIP
2203-008876	C8004,C8006,C8008	C-CERAMIC,CHIP
2203-008876	C8009,C8013,C8014	C-CERAMIC,CHIP
2203-008876	C8016,C8020,C8021	C-CERAMIC,CHIP
2203-008876	C8032,C8037,C8038	C-CERAMIC,CHIP
2203-008876	C8041,C8042,C8045	C-CERAMIC,CHIP
2203-008876	C8047,C8050,C8051	C-CERAMIC,CHIP
2203-008876	C8052,C8053,C8067	C-CERAMIC,CHIP
2203-008876	C8089,C8100,C8102	C-CERAMIC,CHIP
2203-008876	C8113,C8164,C9026	C-CERAMIC,CHIP
2203-008876	C9028,C9045,R10005	C-CERAMIC,CHIP
2203-008886	C11005,C11007	C-CERAMIC,CHIP
2203-008886	ZD11000,ZD11001	C-CERAMIC,CHIP
2203-009025	C2024	C-CERAMIC,CHIP

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2203-009064	C7002,C7003,C7005	C-CERAMIC,CHIP
2203-009064	C7007,C7008,C7018	C-CERAMIC,CHIP
2203-009064	C7019,C7020,C7022	C-CERAMIC,CHIP
2203-009064	C7051,C7114	C-CERAMIC,CHIP
2203-009167	C5070,C5073	C-CERAMIC,CHIP
2203-009220	C11012	C-CERAMIC,CHIP
2203-009444	C8106	C-CERAMIC,CHIP
2203-009537	C12016,C12017,C7048	C-CERAMIC,CHIP
2203-009551	C1049,C12035	C-CERAMIC,CHIP
2203-009618	C10010,C12001,C12002	C-CERAMIC,CHIP
2203-009618	C12003,C12004,C12005	C-CERAMIC,CHIP
2203-009618	C5040	C-CERAMIC,CHIP
2203-009733	C10003,C10005,C10017	C-CERAMIC,CHIP
2203-009733	C10044,C10085,C10087	C-CERAMIC,CHIP
2203-009733	C1105,C1106,C12006	C-CERAMIC,CHIP
2203-009733	C12007,C12044,C8022	C-CERAMIC,CHIP
2203-009733	C8088,C9012,C9016	C-CERAMIC,CHIP
2203-009735	C7098,C7102	C-CERAMIC,CHIP
2203-009736	C10027,C10029,C10048	C-CERAMIC,CHIP
2203-009736	C10049,C10051,C10075	C-CERAMIC,CHIP
2203-009736	C10076,C10081,C10082	C-CERAMIC,CHIP
2203-009736	C10083,C10084,C10092	C-CERAMIC,CHIP
2203-009736	C10099,C10100,C10101	C-CERAMIC,CHIP
2203-009736	C10102,C10103,C10104	C-CERAMIC,CHIP
2203-009736	C10105,C10106,C3014	C-CERAMIC,CHIP
2203-009736	C3018,C9020	C-CERAMIC,CHIP
2203-009812	C8119	C-CERAMIC,CHIP
2203-009858	C4002,C4010,C5059	C-CERAMIC,CHIP
2203-009858	C5060,C5065,C8000	C-CERAMIC,CHIP
2203-009858	C8001,C8002,C8003	C-CERAMIC,CHIP
2203-009858	C8125,C8126,C8129	C-CERAMIC,CHIP
2203-009858	C8138	C-CERAMIC,CHIP
2203-009859	C12000,C12013,C12014	C-CERAMIC,CHIP
2203-009969	C9000,C9002,C9003	C-CERAMIC,CHIP
2203-009969	C9005	C-CERAMIC,CHIP
2203-009987	C10028,C10045,C10046	C-CERAMIC,CHIP
2203-009987	C10047,C4008,C4009	C-CERAMIC,CHIP
2203-009987	C8085,C8086,C8087	C-CERAMIC,CHIP
2203-010085	C8040,C8081,C8082	C-CERAMIC,CHIP

5. MAIN Electrical Parts List

2203-010085	C8083,C8084,L8018	C-CERAMIC,CHIP
2409-001387	TA8006,TA8007	CAPACITOR
2409-001400	TA8000,TA8001,TA8002	CAPACITOR
2409-001400	TA8003,TA8004,TA8005	CAPACITOR
2703-002170	L1015	INDUCTOR
2703-002901	L1021	INDUCTOR
2703-002955	C2008,L1014	INDUCTOR
2703-002958	L1037,L1065,L2005	INDUCTOR
2703-002958	L2010,L2013,L2014	INDUCTOR
2703-002958	L2015,L2018,L2031	INDUCTOR
2703-002958	L2033	INDUCTOR
2703-002959	L10008,L10015,L10016	INDUCTOR
2703-002961	L1020	INDUCTOR
2703-002999	L1010,L2030	INDUCTOR
2703-003479	L2017	INDUCTOR
2703-004012	C1029,L1023,L1033	INDUCTOR
2703-004012	L1042,L1048,L1051	INDUCTOR
2703-004012	L1052,L2026,L2032	INDUCTOR
2703-004012	L2042	INDUCTOR
2703-004013	C2014,L1004,L1076	INDUCTOR
2703-004013	L2016,L5012	INDUCTOR
2703-004014	C1047,C1076,C2049	INDUCTOR
2703-004014	C5020,C5029,L1026	INDUCTOR
2703-004014	L1050,L2037	INDUCTOR
2703-004018	C2004,L1064,L5040	INDUCTOR
2703-004034	C2018,C2027	INDUCTOR
2703-004034	L1058,L2021,L2027	INDUCTOR
2703-004034	L2043,L2057	INDUCTOR
2703-004036	C2007,L2006	INDUCTOR
2703-004038	C1050,C1079,L1000	INDUCTOR
2703-004038	L1038,L1045	INDUCTOR
2703-004287	L1040	INDUCTOR
2703-004300	C2012,C5021,L2028	INDUCTOR
2703-004300	L2045,L5025	INDUCTOR
2703-004363	L2038	INDUCTOR
2703-004371	C1084	INDUCTOR
2703-004703	L1005,L1006,L1029	INDUCTOR
2703-004703	L1053,L1062,L5052	INDUCTOR
2703-004703	L5055,L5057	INDUCTOR

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

2703-004853	L1019,L11000	INDUCTOR
2703-005058	L4001	INDUCTOR
2703-005067	L10001,L10002,L10003	INDUCTOR
2703-005067	L12007,L5039	INDUCTOR
2703-005085	C1027,C1046,C1061	INDUCTOR
2703-005085	C1085,C2020,C2035	INDUCTOR
2703-005085	C2039,L1032,L1035	INDUCTOR
2703-005085	L1043,L1063,L5024	INDUCTOR
2703-005086	C1071,C1074,C2028	INDUCTOR
2703-005086	L1022,L1049,L1054	INDUCTOR
2703-005086	L1056,L5008,L5018	INDUCTOR
2703-005087	L2025,L2036,L5041	INDUCTOR
2703-005088	L1041	INDUCTOR
2703-005089	L1028,L5050	INDUCTOR
2703-005200	L5033,L5035	INDUCTOR
2703-005201	L8001,L8003,L8004	INDUCTOR
2703-005201	L8005,L8008,L8009	INDUCTOR
2703-005201	L8010,L8011,L8017	INDUCTOR
2703-005201	L8026	INDUCTOR
2703-005224	L12000	INDUCTOR
2703-005225	L10000,L4000,L8027	INDUCTOR
2703-005233	L8024,L8025,L9000	INDUCTOR
2703-005233	L9001,L9005,L9007	INDUCTOR
2703-005295	L1008,L1013,L5014	INDUCTOR
2703-005296	L2009	INDUCTOR
2703-005418	L12006	INDUCTOR
2703-005430	L1072	INDUCTOR
2703-005505	L1074,L9002,L9003	INDUCTOR
2703-005509	L8002,L8006,L8007	INDUCTOR
2703-005509	L8012,L8013,L8014	INDUCTOR
2703-005509	L8015,L8016,L8022	INDUCTOR
2703-005555	L5047,L5048	INDUCTOR
2703-005614	L1059,L5042	INDUCTOR
2703-005660	L8023	INDUCTOR
2703-005663	L12003,L12004	INDUCTOR
2801-005393	OSC8000	CRYSTAL-UNIT
2805-001118	OSC5000	OSCILLATOR
2805-001128	TCX4000	OSCILLATOR
2901-001690	C7004,C7006,C7017	FILTER

5. MAIN Electrical Parts List

2901-001690	C7021,C7037,C7038	FILTER
2901-001690	C7039,C7040,C7049	FILTER
2901-001690	C7054,C7063,C7094	FILTER
2901-001690	C7099,C7100,C7101	FILTER
2901-001690	C7103,C7107	FILTER
2903-001576	F5001	FILTER
2904-002270	F2007	FILTER
2904-002296	F1001	FILTER
2904-002356	F5008	FILTER
2904-002362	C1077,F2005	FILTER
2904-002378	F2002	FILTER
2904-002393	F5005	FILTER
2904-002397	F2003	FILTER
2904-002401	F5003	FILTER
2904-002403	F1002	FILTER
2909-001422	F5006	FILTER
2911-000453	F2000	FILTER
2911-000455	F2004,U2000	FILTER
3003-001243	AU9000	MIC-CONDENSOR
3003-001253	MIC9000	MIC-CONDENSOR
3301-001885	L9006	CORE-FERRITE BEAD
3301-001989	L12009	CORE-FERRITE BEAD
3301-002223	L10004,L10007,L10010	CORE-FERRITE BEAD
3301-002223	L10012,L10013,L10014	CORE-FERRITE BEAD
3301-002228	L9004	CORE-FERRITE BEAD
3301-002235	L11001,L11002,L5045	CORE-FERRITE BEAD
3301-002235	L5046	CORE-FERRITE BEAD
3301-002237	L1001,L1009,L1011	CORE-FERRITE BEAD
3301-002237	L1034,L2001,L2002	CORE-FERRITE BEAD
3301-002237	L2007,L2011,L2012	CORE-FERRITE BEAD
3301-002237	L5038,L9011,R5000	CORE-FERRITE BEAD
3301-002238	L12008,L5060	CORE-FERRITE BEAD
3301-002239	L1016,L12010,L8030	CORE-FERRITE BEAD
3301-002243	L1007	CORE-FERRITE BEAD
3301-002244	L1073	CORE-FERRITE BEAD
3301-002279	L10017,L10018,L10019	CORE-FERRITE BEAD
3301-002312	L1069,L12001,L12002	CORE-FERRITE BEAD
3301-002312	L12005,L4002,L5029	CORE-FERRITE BEAD
3301-002312	L5058,L5059	CORE-FERRITE BEAD

5. MAIN Electrical Parts List

3301-002331	L8020,L8021,L9010	CORE-FERRITE BEAD
3301-002375	L9008,L9009	CORE-FERRITE BEAD
3705-001708	RFS100,RFS1001	CONNECTOR-COAXIAL
3709-001892	CN4000	CONNECTOR-CARD EDGE
3711-008847	HDC8000	CONNECTOR-HEADER
3711-008997	HEA9000	CONNECTOR-HEADER
3711-009356	HEA10001	CONNECTOR-HEADER
3711-009359	HEA10003,HEA12000	CONNECTOR-HEADER
3711-009407	HEA10002	CONNECTOR-HEADER
3712-001604	ANT1003,ANT1005	CONNECTOR
3712-001604	ANT1006,ANT1007	CONNECTOR
3712-001604	ANT1008,ANT1010	CONNECTOR
3712-001604	ANT1011,ANT8000	CONNECTOR
3712-001604	ANT8001,ANT8002	CONNECTOR
3712-001604	ANT8003,ANT8004	CONNECTOR
3712-001604	ANT8005,ANT8006	CONNECTOR
3712-001633	ANT8007,ANT8008	CONNECTOR
3712-001634	ANT4000,ANT4001	CONNECTOR
3712-001634	ANT4002,ANT4003	CONNECTOR
3712-001634	ANT4004,ANT4005	CONNECTOR
3712-001666	ANT1002,ANT1004	CONNECTOR
3712-001666	ANT5003,ANT5004	CONNECTOR
3712-001666	ANT9002,ANT9003	CONNECTOR
3712-001666	SANT2002,SANT2008	CONNECTOR
3712-001694	ANT1012,ANT11000	CONNECTOR
3712-001694	ANT11001,ANT11002	CONNECTOR
3712-001694	ANT11003,ANT11004	CONNECTOR
3712-001694	ANT11005,ANT11006	CONNECTOR
3712-001694	ANT11007,ANT11008	CONNECTOR
3712-001694	ANT5000,ANT5001	CONNECTOR
3712-001694	ANT5002,ANT5005	CONNECTOR
3712-001694	SANT2000,SANT2001	CONNECTOR
3712-001694	SANT2005,SANT2006	CONNECTOR
3712-001694	SANT2007	CONNECTOR
3712-001714	ANT9000,ANT9001	CONNECTOR
3712-001731	ANT1001,SANT2003	CONNECTOR
3712-001731	SANT2004	CONNECTOR
3722-004150	USB11000	JACK-PHONE
4709-002196	F1000	RF-MODULE

Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

5. MAIN Electrical Parts List

4709-002285	F5004	RF-MODULE
4709-002716	U5003	RF-MODULE

Please consult the GSPN website (Samsung Portal) for the most recent version of the product's part list.